

To correctly position the WC Pan, the cabinet lower panel will need to be in position and cut out to expose the inlet & outlet pipework as indicated (A)

Measure the distance from the lower panel to the WC Pan fixing hole (B) and at this point on the floor fix some masking tape and mark the centre line as shown (C).

Place the WC Pan in position and mark the inner & outer edges on the masking tape (D).

Remove the WC Pan and fix the floor brackets in line with the inner edge (E).

The lower panel can then be removed for any other works to be completed and then returned to position along with the WC Pan for the final connections.

