

# Pentland Plinth | Fitting Instructions

## Fitting the Pentland two piece plinth

To assemble the Pentland 2 - piece plinth we recommend using countersunk screws 3.5mm x 35mm and to fix through the top of the pelmet section in to the top edge of the fascia as shown below.

To avoid either part splitting they must be pre-drilled with a suitable pilot drill and the top surface of the pelmet countersunk. Alternatively, or as a further strengthening, they can also be bonded with a suitable contact adhesive.

The assembled plinth can then be clipped to the carcass legs in the normal way as indicated in the lower sketch.

